

FLASH OVEN CLEANER

FOR CLEANING OVENS AND GRILLS

GENERAL DESCRIPTION: A tough ready-to-use caustic compound for the cleaning of ovens and grills. Can be sprayed or brushed on.

ADVANTAGES: Tough caustic formula

Ready-to-use

May be sprayed or brushed on

Fast acting

PROPERTIES: Color Amber

Odor Mild butyl odor

Form Liquid Solubility High

pH-1% solution Approx: 12 to 12.5

APPLICATION: Wear rubber gloves, eye protection and long sleeves. For ovens: spray or brush cleaner on warm (less than 180 degrees F.) oven surface. Let the cleaner sit for at least 1 minute, then wipe off with damp cloth or sponge. For grills: scrape grill surface as clean as possible and wipe off with cloth. Spray or brush cleaner on warm (less than 180 degrees F.) grill. Let cleaner set for at least 1 minute, then wipe off with damp cloth. After grill is clean, neutralize surface by wiping grill with a dilute solution of vinegar.

CAUTION: Corrosive to skin, eyes, and mucous membranes and will cause severe burns. Avoid contact. Keep out of reach of children.

Always consult the MSDS sheet for any hazardous ingredient information, precautions for safe handling and use, health hazard data, or other information regarding this product.