

HD LIME REMOVER

FOR THE REMOVAL AND CONTROL OF LIME DEPOSITS

GENERAL DESCRIPTION: HD LIME REMOVER is formulated to remove and control lime deposits, water spots, and stains on sinks, faucets, drain boards and glassware caused by hard water. Also keeps lime deposits under control in dishwashing machines.

ADVANTAGES: Concentrated – quicker results

Easily removes lime deposits Removes water spotting on glasses May be used in dishwashing machines

PROPERTIES: Color Pale green

Odor Faint acid odor

Form Liquid Solubility Complete pH-1% solution 1.0 to 2.0

APPLICATION: For drainboards, faucets and sinks apply **HD LIME REMOVER** directly on area to be cleaned and wipe with a damp cloth. For water spots on glassware use one ounce of **HD LIME REMOVER** in 3 gallons of water. Rinse with fresh water. For de-scaling dishwashers, pour 2 cups of **HD LIME REMOVER** into the dishwasher and run for 5 minutes. Drain tank. Rinse with fresh water.

CAUTION: Contains phosphoric acid. Material is corrosive to eyes, skin, and mucous membranes and will cause severe burns. Avoid contact. Keep out of reach of children.

PACKAGING: Case 4/gal.

Always consult the MSDS sheet for any hazardous ingredient information, precautions for safe handling and use, health hazard data, or other information regarding this product.

LUSEAUX® Laboratories, Inc.

DETERGENTS • CLEANERS • SANITIZERS